



The Remote Instructions

Firstly setting the Time/Month/Year:

Turn the remote on with the power button located on the top right of the keypad.

Press the right-hand arrow button until you get to the screen where you see 1-7 down the left-hand side and ProgU1 at the top right-hand side and a time setting in the centre.

If you press the left-hand arrow once, you will see the clock symbol at the bottom of the screen and 1-7 down the left-hand side. Press OK and the hours will begin to flash, use the UP and DOWN arrows to change the hour then press OK, it will then move on to the minutes. Use the UP and DOWN arrows again to adjust then press OK.

Next- you will see it is asking you to key in the YEAR, so again if you use the UP or DOWN arrow and keep pressing until it changes to 2015 then press OK.

Next - the MONTH, use the UP and DOWN arrows to change to the correct month, press OK then change the date to the correct date. Press OK one final time to save and exit.

This will take you back to the programme screen where it will automatically change to the correct day.

There are 9 different built in programme modes, you can go through the modes by scrolling with the UP and DOWN arrows. Once you have selected the programme you require, press the bottom right-hand button (up facing arrow with three curved lines above) on the keypad and point at the radiator to transmit the programme across.

Alternatively you can set your own programme with the ProgU1-U5 modes. Using the UP and DOWN arrows to scroll through which programme you would like to use, then press ok then ok again to access and enter the programme. You will see 0.00 flashing.

Then you will need to programme in your own desired time settings for the radiator to come on and off through the day.

Press the frost button (snowflake symbol) up to the time you want the radiator on (you will notice the time going up in half hour intervals), once you are at the required time, press the sun button until you require the heating to go off again, then back to the frost button until you would like to turn the heating back on and then again to the sun until you want it to go off in the evening. Finally press the frost button until midnight to turn it off at the end of the evening/night. Once you see 0:00 on the screen press OK and day 1 will be saved.

If you would like to duplicate the programme sequence on day 1 for every day of the week, simply press OK and watch the arrow on the left hand side drop down from 1 to 7. On the 7th day press OK again to save the entire week.

Alternatively, programme each day individually, remembering to press OK when reaching 0:00 to save the settings for that day.

Once programmed, press the transmit button at the bottom right of the remote and point this at the radiator. It should display PRO so you know it is following the programme set. Please leave your radiator on this screen for it to follow the programme.
Information on the different modes:

COMFORT (sun symbol):

In this mode you select the temperature desired between 7 - 30° C in steps of 0.5° C. The recommended temperature of comfort is around 20 - 22° C but it depends how warm or cold the property is. Comfort mode is used whenever you would like heating.

ECONOMY (crescent moon symbol):

In this economy mode the programmed temperature is automatically set at 4° less than the comfort mode temperature.

The economy mode is used in the hours before the full heat of comfort mode is to click on, avoiding heating up from low temperatures.

Frost (snowflake symbol):

In this mode the temperature is fixed to 7° c, therefore if the room temperate is ever to fall below 7° c the radiator will click on. This is to ensure the pipework in the property isn't damaged.

This is often used overnight and through the day when the heating is to be off.